



**Remarks:**

1. All dimensions in mm.
2. Prepare foundation with concrete class C20/25. Concrete must be reinforced with reinforcement bars or fibres and flat on top.
3. For turnstile instalation, place turnstile on prepared foundation - wire pipes with 230VAC supply should be just under main posts, lay out and drill holes for appropriate anchors.
4. Placing turnstile on foundation depends on detailed turnstile size - to be chosen on installation site.
5. This is suggested foundation plan, dimensions, reinforcements, anchoring.

	Remarks			
	Designed by K.Kowalski	Scale 1 : 20	Format A3	Data 17.06.2021
Edited by	Height	Width	Material C20 25	Mass N/A
Number S.002705	Drawing 3ar 900 Foundation Plan			Rev. A